




Prime-200INT



Please install "Tee" , according to the direction of!

Prime-200INT



1. Screw the output pipe to the pump's output (make sure the O Ring is in place)
2. push pump body onto bracket
3. Installed (rotation) the customet volute to pump body

AQ-3000S customer volute pump Assemble